



# Automated Traffic Signal Performance Measures

HELPING TRAFFIC ENGINEERS MANAGE DATA TO MAKE BETTER DECISIONS

PRESENTED BY AMANDA STEVENS, P.E. 3/31/14



#### What is TIG?

- AASHTO TECHNOLOGY IMPLEMENTATION GROUP
- ACCELERATED ADOPTION VIA TECH ASSISTANCE AND SHARED RESOURCES
- HIGH-PAYOFF, MARKET-READY TECHNOLOGIES

Who are the Lead States for TIG's Automated Signal Performance Measures?





INDIANA TOLEVARTMENT OF TRANSPORT

MINNESOTA



**UTAH** 



#### Pooled Fund Study 5(258):



#### TRANSPORTATION POOLED FUND PROGRAM

Username:

Password:

Login

Forgot your username or password?

hat is an authorized user?

Home | About TPF | How to Participate | Open Solicitations | Search | Forms | Success Stories | Related Links | Email Alerts

Home > Home > Search Solicitations and Studies > Study Detail View Study Detail View

#### **Study Detail View**

Traffic Signal Systems Operations and Management

#### General Information

Study Number: TPF-5(258) Status: Cleared by FHWA

Lead Agency: Indiana Department of Transportation

Contract Start Date: Est. Completion Date:

Partners: City of Chicago , CA , GA , KS , MN , MS , NH , TX , UT , WisDOT


Contract/Other Number:


Last Updated: Oct 18, 2011


Contract End Date:




What are Traffic Signal Performance Measures?









#### **SIGNAL DATA**








### Why Automated Traffic Signal Performance Measures?



**Manage Resources** 



Minimize Traffic Delay



Communicate Results

Active Phase Events:		Detector Events:				
0	Phase On	Phase # (1-16)	81	Detector Off	DET Channel # (1-64)	
1	Phase Begin Green	Phase # (1-16)	82	Detector On	DET Channel # (1-64)	
2	Phase Check	Phase # (1-16)	83	Detector Restored	DET Channel # (1-64)	
3	Phase Min Complete	Phase # (1-16)	84	Detector Fault- Other	DET Channel # (1-64)	
4	Phase Gap Out	Phase # (1-16)	85	Detector Fault-Watchdog Fault	DET Channel # (1-64)	
5	Phase Max Out	Phase # (1-16)	86	Detector Fault- Open Loop Fault	DET Channel # (1-64)	
6	Phase Force Off	Phase # (1-16)	Preempti	on Events:		
7	Phase Green Termination	Phase # (1-16)	101	Preempt Advance Warning Input	Preempt # (1-10)	
8	Phase Begin Yellow Clearance	` '	102	Preempt (Call) Input On	Preempt # (1-10)	
9	Phase End Yellow Clearance	Phase # (1-16)	103	Preempt Gate Down Input Received	Preempt # (1-10)	
10	Phase Begin Red Clearance	Phase # (1-16)	104	Preempt (Call) Input Off	Preempt # (1-10)	
11	Phase End Red Clearance	Phase # (1-16)	105	Preempt Entry Started	Preempt # (1-10)	

#### **Controller Enumerations**


**Event Code, Event Description, Parameter** 

	06/27/2013 01:29:51.1	10	8
	06/27/2013 01:29:51.1	82	5
	06/27/2013 01:29:52.2	1	2
Time: 1:29:51.1	06/27/2013 01:29:52.2	1	6
Code: 82 (ON)	06/27/2013 01:29:52.3	82	2
	06/27/2013 01:29:52.8	82	4
Parameter: 5 (Det. Ch.)	06/27/2013 01:29:52.9	81	4
	06/27/2013 01:29:53.3	81	6
	06/27/2013 01:29:54.5	81	2
	06/27/2013 01:30:02.2	8	2
Ti 1.20.00 1	06/27/2013 01:30:02.2	8	6
Time: 1:30:08.1	06/27/2013 01:30:02.2	33	2
Code: 1 (Green)	06/27/2013 01:30:02.2	33	6
	06/27/2013 01:30:02.2	32	2
Parameter: 8 (Phase)	06/27/2013 01:30:02.2	32	6
	06/27/2013 01:30:06.1	10	2
	06/27/2013 01:30:06.1	10	6
	06/27/2013 01:30:08.1	1	8
Time: 1:30:15.8	06/27/2013 01:30:13.1	32	8
	06/27/2013 01:30:15.8	81	5
Code: 81 (OFF)	06/27/2013 01:30:18.5	82	6
Parameter: 5 (Det. Ch.)	06/27/2013 01:30:27.5	81	6
	06/27/2013 01·30·30 ∆	8	ρ

#### **High Resolution Data**

Timestamp, Enumeration Code, Parameter

#### Today's Goals:




Purdue Coordination Diagram (PCD)




Performance Measures for YOUR Agency



**Get Started!** 




#### PCD: Red Arrival





#### PCD: Green Arrival






### PCD: Platoon Arrival by TOD






#### **PCD:** Distinct Platoons






### PCD: Cycle Failure




### PCD: Early Platoon Arrival







PCD: Platoon Clipping




PCD: Adjust Offsets



#### PCD: Pattern Start & End Times




### **BEFORE Offset Optimization**



### **AFTER Offset Optimization**

#### Today's Goals:



Purdue Coordination Diagram (PCD)



Performance Measures for YOUR Agency




**Get Started!** 




# HCM & Signal Performance Measures


- FLOW RATE
- LEVEL OF SERVICE
- VOLUME / CAPACITY RATIO
- ORIGIN-DESTINATION DISTRIBUTION (FOR CLOSELY SPACED INTERSECTIONS)
- VEHICLE DELAY
- PLATOON RATIO
- QUEUE LENGTH
- PROPORTION ARRIVAL ON GREEN
- PASSAGE TIMES
- VEHICLE SPEED (RADAR OR PROBE DATA)
- LANE UTILIZATION
- PEDESTRIAN/BIKE/PREEMPTION ACTIVITY



#### **Volumes by TOD**



#### Volume to Capacity Ratio




#### **Example Calculations:**

75% AOG 50% Green Time = 1.5


 $\frac{50\% \text{ AOG}}{50\% \text{ Green Time}} = 1.0$ 

**50% AOG** = 0.67 75% Green Time

#### **Platoon Ratio**



Purdue Phase Termination Diagram



# What is the Best Infrastructure for Automated Signal Performance Measures?




#### What are minimum requirements for PCD's?

Controller



**Advanced Detection** 



## What are the minimum requirements for Automated Signal Performance Measures?




High Resolution Controller

Computer



# What Agency Tasks can be Automated?

- OPTIMIZE TRAFFIC FLOW
- AUTOMATE REPORTS
  - Management
  - Maintenance
  - Signal Systems Engineering
- ARCHIVE SIGNAL DATA
- INFORMATION ACCESS FOR STAKEHOLDERS
- MONITOR SIGNAL TIMING USING THRESHOLD ALARMS



UDOT's Signal Performance Website

### "Traffic Was Bad Saturday!"

- Monday Customer Service Report



- WAS SATURDAY TYPICAL?
  - An accident?
  - Equipment failures?
  - Have timings changed?
  - Unusually High Volumes?
- DOES SATURDAY NEED RETIMED?
  - Gather Counts & Model new plan?
  - Schedule Saturday field retiming?
  - Can we fix a timing issue today?
- NEXT SATURDAY: DID WE FIX THE PROBLEM?

# What do Automated Traffic Signal Performance Measures mean to you?



Always on...




Measure vs. model...



Improved mobility...

#### Today's Goals:



Purdue Coordination Diagram (PCD)



Performance Measures for YOUR Agency



**Get Started!** 



#### Get Started with TIG!

- ITE WEBINAR APRIL 9<sup>TH</sup>, MAY 7<sup>TH</sup>, JUNE 11<sup>TH</sup>
- SERVER/WEBSITE EXPERTISE
- OPEN SOURCE CODE
- PROCUREMENT SPECIFICATION EXAMPLES





# Thank you. QUESTIONS?

www.tig.transportation.org

AUTOMATED TRAFFIC SIGNAL PERFORMANCE MEASURES

